RH520A Humidity + Temperature Chart Recorder



This paperless chart recorder provides simultaneous digital and graphical display of %RH and Temperature or Dew Point. The display also shows date/time and Min/Max measurements. Stored readings can be recalled on the display or downloaded to a PC. ExChart PC software is included for download control and to graph %RH. Ambient Temperature, Dew Point, Wet Bulb, and GPP or g/kg. Provisions for wall mounting or the control panel swivels to act as a desk stand. The user can set audible and visual alarms with High and Low limits for Humidity and Temperature.



Features

- · Simultaneous numerical and graphical display of Humidity and Temperature or Dew Point readings, plus Time & Date
- Measures Humidity (10 to 95%RH) and Temperature (-20.0°F to 140.0°F) plus included ExChart software to calculate and graph Dew Point, Wet Bulb, and GPP (grains per pound)
- Large dual graphical LCD displays with adjustable vertical and horizontal TAC resolution
- Internal memory records up to 49,000 data points and can be transferred to a PC for further data analysis
- LCD indicates percentage of memory remaining

- Replaceable probe does not require recalibration
- Detachable probe extends up to 1 meter for measurements in closed environments
- Audible and visual alarm with Hi/Low setpoints
- Output socket used with optional external alarm
- · Scroll the cursor to display selected data recorded
- Desk or wall mount
- · Complete with built-in stand, detachable probe with 3ft (1m) cable, RS-232 cable, USB adaptor, Windows® compatible software, AC adaptor, and 3 AA batteries

Range	Basic Accuracy	
10.0 to 95.0%	±3% RH	
-20.0 to 140.0°F (-28.0 to 60.0°C)	±1.8°F (±1°C)	
5 x 7.7 x 0.9" (129x195x22mm)		
12.6oz (357g)		
	10.0 to 95.0% -20.0 to 140.0°F (-28.0 to 60.0°C) 5 x 7.7 x 0.9" (129x195x22mm)	10.0 to 95.0% ±3% RH -20.0 to 140.0°F (-28.0 to 60.0°C) ±1.8°F (±1°C) 5 x 7.7 x 0.9" (129x195x22mm)

Ordering

RH520A **Humidity + Temperature Chart Recorder
RH520A-220 **Humidity + Temperature Chart Recorder (220V)
RH520A-240 **
RH522Replaceable Humidity/Temperature Probe

M)* Indicates products that are available with optional calibration traceable to NIST. Order with -NIST after part number for product plus Calibration Certificate.

RH520A UPC Code: 793950445204

RH520A-220 UPC Code: 793950442203 RH520A-240 UPC Code: 793950442401